

N70 HILUX MUD FLAP FITTING INSTRUCTIONS

**YOU WILL NEED TO HAVE OR DO A GUARD CHOP
THESE INSTRUCTIONS ARE DONE WITH 60MM UTE MART FLARES, PLEASE
USE YOUR BEST JUDGEMENT IF YOU HAVE DIFFERENT FLARES**



STEP ONE: Peel back the inner guard & remove the bottom screw hole. Cut your flare to suit.



STEP TWO: Install the provided pinch weld on this cut.



STEP THREE: Reinstall the inner guard.



STEP FOUR: Install the mud flap.



You will want the mud flap to sit flush with your flare. You may need to cut more out depending on your flare and your original cut.



JOB DONE!